

□□□:	□□□ □□ □□ □□ □□ □□
□□ □□:	0132
□□ □ □□ :	□□ □□ Nubuck leahter PU / PU □□ □□ □□ (MD □□□ □□)
□□□:	1. □□□ □□ □□ □□□ □□. (ASTM F2413-18 M I / 75 C / 75, CE ENISO 20345 STANDARD, □□□ □□ □□ □□)
	2. □ □□ □□□□ □□□□□.
□□ : (□□ □□)	1. □□ □□□□ □□ □□□□. (ASTM F2413-18 M I / 75 C / 75, CE ENISO 20345 STANDARD, □□□ □□ □□ □□)
	2. □□ □□ □□
□□:	□□□ PU □□ □□ □□
□:	□□□ □□□□ □□□□ □□
□□:	□□□ □□ □□□□ □□ □□
□□ :	□□ □□ □□□□ □□ □ □□ □ HI-POLY
□□:	PU □□
□□:	6 □□
□□:	38 ~ 46 □□
□□:	12 □□, □□□ □□.
□□□:	□□ □ □□ □□, □□□□□ 10 □
□□ □□	59 x 44 x 33cm
□□□□□ □□□ :	2600pairs / 1x20 '□□□□□ 6500pairs / 1x40'□□□□□

□□□ □□□ □□ :

We are the manufacturer of safety shoes. It's our honor to introduce

CREATIVITY SOLE

**NEW
DESIGN**



- **New Technical PU Injection Sole.**
- **We Can Make The Sole Appearance Same As MD (Moulded) Sole, But We Are Injection, They Are Cemented.**
- **The Connected Border Is More Tidy And Clean.**
- **The Shoe Of Cemented MD Sole Degum Easily.**
- **Put On Our Shoe From Now On To Say "BYE BYE" to degumming shoe.**



QUALITY
WARRANTY
12 MONTHS



0132 □□ □□□ □□ □□ □ :



Canton Fair



SAFETY SHOES



RAIN BOOTS



PROFESSIONAL SAFETY SHOE & RAIN BOOT FACTORY